miércoles, 4 de junio de 2025 | Mileage: 315 km

All All

Click to PRINT Vehicle History

Sequence	Action	Start Time	End Time	Resource ID	Technician
1	Network Test	11:47 a. m.	11:48 a. m.	JavaNTest	
2	Self Test	11:48 a. m.	12:44 p. m.	G1823198	

Self Test results View CMDTCs Last Updated 11:49:09 a. m.

Module	Network	DTC	FT	ST	Description	DTC Type	Time Since Set
ABS	FD1	U3001	68	28	- Control Module Improper Shutdown Performance	CMDTC	19:31:00

ABS - U3001 : 68 : 28
U3001 = Control Module Improper Shutdown Performance
FT : 68 = Event Information
ST : 28 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

+ Freeze Frame / Snapshot

ABS	FD1	U3012	68	28	- Control Module Improper Wake-up Performance	CMDTC	111 días 07:12:00

ABS - U3012 : 68 : 28
U3012 = Control Module Improper Wake-up Performance
FT : 68 = Event Information
ST : 28 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

+ Freeze Frame / Snapshot

ACM	HS3	B150C	87	08	- Automobile Audio Bus (A2B) Node 1	CMDTC	

ACM - B150C : 87 : 08
B150C = Automobile Audio Bus (A2B) Node 1
FT : 87 = Missing Message
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

ACM	HS3	B1511	13	0B	- Automobile Audio Bus (A2B) Master Node	CMDTC	

ACM - B1511 : 13 : 0B
B1511 = Automobile Audio Bus (A2B) Master Node
FT : 13 = Circuit Open
ST : 0B = Current DTC. Fault is currently present.
This module uses GGDS Format 00 DTC descriptions.

ACM	HS3	U0238	00	0B	- Lost Communication With Digital Audio Control Module 'D'	CMDTC	

ACM - U0238 : 00 : 0B
U0238 = Lost Communication With Digital Audio Control Module 'D'
FT : 00 = No Sub Type Information
ST : 0B = Current DTC. Fault is currently present.
This module uses GGDS Format 00 DTC descriptions.

ACM	HS3	U3003	16	08	- Battery Voltage	CMDTC	

ACM - U3003 : 16 : 08
U3003 = Battery Voltage
FT : 16 = Circuit Voltage Below Threshold
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

APIM	HS3	U0238	00	0B	- Lost Communication With Digital Audio Control Module 'D'	CMDTC	

APIM - U0238 : 00 : 0B
U0238 = Lost Communication With Digital Audio Control Module 'D'
FT : 00 = No Sub Type Information
ST : 0B = Current DTC. Fault is currently present.
This module uses GGDS Format 00 DTC descriptions.

ATCM	HS1	B11D9	16	08	- Vehicle Battery	CMDTC	

ATCM - B11D9 : 16 : 08
B11D9 = Vehicle Battery
FT : 16 = Circuit Voltage Below Threshold
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

BCM	HS1	U211B	43	48	- Control Module Message Authentication	CMDTC	

BCM - U211B : 43 : 48
U211B = Control Module Message Authentication
FT : 43 = Special Memory Failure
ST : 48 = Indeterminate. Fault previously detected, but monitor has not completed to determine state.
This module uses GGDS Format 00 DTC descriptions.

BCM	HS1	U3006	16	08	- Control Module Input Power 'A' Circuit/Open	CMDTC	

BCM - U3006 : 16 : 08
U3006 = Control Module Input Power 'A' Circuit/Open
FT : 16 = Circuit Voltage Below Threshold
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

BCM	HS1	U3007	16	08	- Control Module Input Power 'B' Circuit/Open	CMDTC	

BCM - U3007 : 16 : 08
U3007 = Control Module Input Power 'B' Circuit/Open
FT : 16 = Circuit Voltage Below Threshold
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

BCM	HS1	U3013	16	08	- Control Module Input Power 'C' Circuit/Open	CMDTC	

BCM - U3013 : 16 : 08
U3013 = Control Module Input Power 'C' Circuit/Open
FT : 16 = Circuit Voltage Below Threshold
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

BCM	HS1	U3014	16	08	- Control Module Input Power 'D' Circuit/Open	CMDTC	

BCM - U3014 : 16 : 08
U3014 = Control Module Input Power 'D' Circuit/Open
FT : 16 = Circuit Voltage Below Threshold
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

	BCMC	FD1	Pass				CMDTC	
	CCM	FD3	Pass				CMDTC	
	CMR	FD3	Pass				CMDTC	
	DCACA	HS1	Pass				CMDTC	
	DDM	FD3	Pass				CMDTC	
	DSM	MS1	Pass				CMDTC	
	DSP	HS3	Fail			Module not Responding	CMDTC	
	GSM	FD3	Pass				CMDTC	
	GWM	HS1	U3003	16	08	- Battery Voltage	CMDTC	

GWM - U3003 : 16 : 08
U3003 = Battery Voltage
FT : 16 = Circuit Voltage Below Threshold
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

	HUD	HS1	U3003	16	08	- Battery Voltage	CMDTC	

HUD - U3003 : 16 : 08
U3003 = Battery Voltage
FT : 16 = Circuit Voltage Below Threshold
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

	HVAC	MS1	Pass				CMDTC	
	IPC	HS3	B108E	02	08	- Display	CMDTC	

IPC - B108E : 02 : 08
B108E = Display
FT : 02 = General Signal Failure
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

	IPC	HS3	B108E	87	08	- Display	CMDTC	

IPC - B108E : 87 : 08
B108E = Display
FT : 87 = Missing Message
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

IPC	HS3	U0232	00	08	- Lost Communication With Side Obstacle Detection Control Module 'A'	CMDTC	

IPC - U0232 : 00 : 08
U0232 = Lost Communication With Side Obstacle Detection Control Module 'A'
FT : 00 = No Sub Type Information
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

IPC	HS3	U0233	00	08	- Lost Communication With Side Obstacle Detection Control Module 'B'	CMDTC	

IPC - U0233 : 00 : 08
U0233 = Lost Communication With Side Obstacle Detection Control Module 'B'
FT : 00 = No Sub Type Information
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

IPC	HS3	U023A	00	08	- Lost Communication With Image Processing Module 'A'	CMDTC	

IPC - U023A : 00 : 08
U023A = Lost Communication With Image Processing Module 'A'
FT : 00 = No Sub Type Information
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

IPC	HS3	U023A	56	08	- Lost Communication With Image Processing Module 'A'	CMDTC	

IPC - U023A : 56 : 08
U023A = Lost Communication With Image Processing Module 'A'
FT : 56 = Invalid/Incompatible Configuration
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

IPC	HS3	U023B	00	08	- Lost Communication With Image Processing Module 'B'	CMDTC	

IPC - U023B : 00 : 08
U023B = Lost Communication With Image Processing Module 'B'
FT : 00 = No Sub Type Information
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

IPC	HS3	U0533	56	08	- Invalid Data Received From Side Obstacle Detection Control Module 'A'	CMDTC	

IPC - U0533 : 56 : 08
U0533 = Invalid Data Received From Side Obstacle Detection Control Module 'A'
FT : 56 = Invalid/Incompatible Configuration
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

IPC	HS3	U0534	56	08	- Invalid Data Received From Side Obstacle Detection Control Module 'B'	CMDTC	

IPC - U0534 : 56 : 08
U0534 = Invalid Data Received From Side Obstacle Detection Control Module 'B'
FT : 56 = Invalid/Incompatible Configuration
ST : 08 = Not a Current DTC. Fault previously detected, not currently present.
This module uses GGDS Format 00 DTC descriptions.

	IPC	HS3	U3003	16	08	- Battery Voltage	CMDTC	
	IPC - U3003 : 16 : 08 U3003 = Battery Voltage FT : 16 = Circuit Voltage Below Threshold ST : 08 = Not a Current DTC. Fault previously detected, not currently present. This module uses GGDS Format 00 DTC descriptions.							
	IPMA	FD3	C1001	97	28	- Vision System Camera	CMDTC	
	IPMA - C1001 : 97 : 28 C1001 = Vision System Camera FT : 97 = Component Or System Operation Obstructed Or Blocked ST : 28 = Not a Current DTC. Fault previously detected, not currently present. This module uses GGDS Format 00 DTC descriptions.							
	IPMA	FD3	B1578	89	28	- Digital Park Assist Camera Vision System	CMDTC	2 días 18:41:00
	IPMA - B1578 : 89 : 28 B1578 = Digital Park Assist Camera Vision System FT : 89 = Data Transfer Failure ST : 28 = Not a Current DTC. Fault previously detected, not currently present. This module uses GGDS Format 00 DTC descriptions.						+ Freeze Frame / Snapshot	
	OCSM	HS1	Pass				CMDTC	
	PCM	HS1	P161C	00	28	- Automatic Engine Shutdown Mismatch with Vehicle Configuration	CMDTC	111 días 07:12:00
	PCM - P161C : 00 : 28 P161C = Automatic Engine Shutdown Mismatch with Vehicle Configuration FT : 00 = No Sub Type Information ST : 28 = Not a Current DTC. Fault previously detected, not currently present. This module uses GGDS Format 00 DTC descriptions.						+ Freeze Frame / Snapshot	
	PCM	HS1	Pass				Permanent	
	PDM	FD3	Pass				CMDTC	
	PSCM	FD3	U3003	68	28	- Battery Voltage	CMDTC	2 días 19:15:00
	PSCM - U3003 : 68 : 28 U3003 = Battery Voltage FT : 68 = Event Information ST : 28 = Not a Current DTC. Fault previously detected, not currently present. This module uses GGDS Format 00 DTC descriptions.						+ Freeze Frame / Snapshot	
	RCM	HS1	U3003	16	08	- Battery Voltage	CMDTC	2 días 19:07:00
	RCM - U3003 : 16 : 08 U3003 = Battery Voltage FT : 16 = Circuit Voltage Below Threshold ST : 08 = Not a Current DTC. Fault previously detected, not currently present. This module uses GGDS Format 00 DTC descriptions.						+ Freeze Frame / Snapshot	
	RGTM	MS2	Pass				CMDTC	

	RTM	MS1	Pass				CMDTC	
	SCCM	FD3	U3000	47	68	- Control Module	CMDTC	
	SCCM - U3000 : 47 : 68 U3000 = Control Module FT : 47 = Watchdog/Safety µC Failure ST : 68 = Indeterminate. Fault previously detected, but monitor has not completed to determine state. This module uses GGDS Format 00 DTC descriptions.							
	SODCMC	FD3	Pass				CMDTC	
	SODCMD	FD3	Pass				CMDTC	
	SODL	FD3	Pass				CMDTC	
	SODR	FD3	Pass				CMDTC	
	TCCM	FD1	P0562	00	08	- System Voltage Low	CMDTC	
	TCCM - P0562 : 00 : 08 P0562 = System Voltage Low FT : 00 = No Sub Type Information ST : 08 = Not a Current DTC. Fault previously detected, not currently present. This module uses GGDS Format 00 DTC descriptions.							
	TCU	FD2	U3003	16	08	- Battery Voltage	CMDTC	
	TCU - U3003 : 16 : 08 U3003 = Battery Voltage FT : 16 = Circuit Voltage Below Threshold ST : 08 = Not a Current DTC. Fault previously detected, not currently present. This module uses GGDS Format 00 DTC descriptions.							
	TRM	HS3	Pass				CMDTC	
	WACM	HS3	U3003	16	08	- Battery Voltage	CMDTC	
	WACM - U3003 : 16 : 08 U3003 = Battery Voltage FT : 16 = Circuit Voltage Below Threshold ST : 08 = Not a Current DTC. Fault previously detected, not currently present. This module uses GGDS Format 00 DTC descriptions.							

Self Test results All CMDTCs Clear and Retest Last Updated 12:09:47 p. m.

3	PTS : VIN 1FTFW4L55SFA41733	12:10 p. m.	12:10 p. m.		
4	PTS : Connected Vehicle Status	12:10 p. m.	12:10 p. m.		
5	PTS : Connected Vehicle Home	12:11 p. m.	12:11 p. m.		
6	PTS : Workshop Manual : 2025 F-150	12:11 p. m.	12:11 p. m.	S10526	

7	PTS : Workshop Manual : 415-00 Sistema de información y entretenimiento - Información general::Diagnóstico y comprobaciones::Sistema de información y entretenimiento	12:12 p. m.	12:12 p. m.	G2474960	
8	PTS : PRUEBA PRECISA C: NO HAY SONIDO EN NINGUNA DE LAS BOCINAS	12:13 p. m.	12:13 p. m.	G2474960	
9	Network Monitor	12:13 p. m.	12:44 p. m.	G1908287	
10	PTS : Workshop Manual : 418-00A Red de comunicaciones del módulo de red de controladores (CAN)::Diagnóstico y comprobaciones::Red de comunicaciones del módulo de red de controladores (CAN)	12:15 p. m.	12:15 p. m.	G2406819	
11	PTS : Workshop Manual : 415-00 Sistema de información y entretenimiento - Información general::Desmontaje e instalación::Módulo de procesamiento de señales digitales de audio (DSP)	12:16 p. m.	12:16 p. m.	G2478999	
12	PTS : Workshop Manual :	12:16 p. m.	12:16 p. m.	G2161239	
13	PTS : Workshop Manual : 501-05 Vestidura y ornamentación interior::Desmontaje e instalación::Panel de vestidura del área para carga - SuperCab/SuperCrew	12:16 p. m.	12:16 p. m.	G2161240	
14	PTS : Workshop Manual : 501-05 Vestidura y ornamentación interior::Desmontaje e instalación::Panel de vestidura del pilar C	12:17 p. m.	12:17 p. m.	G2161229	
15	Network Test	12:49 p. m.	12:50 p. m.	JavaNTest	
16	Network Test	12:50 p. m.	12:51 p. m.	JavaNTest	
17	PTS : VIN 1FTFW4L55SFA41733	12:54 p. m.	12:54 p. m.		
18	PTS : Connected Vehicle Status	12:54 p. m.	12:54 p. m.		
19	PTS : Workshop Manual : 2025 F-150	12:54 p. m.	12:54 p. m.	S10526	
20	Self Test	12:54 p. m.	4:46 p. m.	G1823198	
21	PTS : Workshop Manual : 415-00 Sistema de información y entretenimiento - Información general::Diagnóstico y comprobaciones::Sistema de información y entretenimiento	2:33 p. m.	2:33 p. m.	G2474960	
22	PTS : PRUEBA PRECISA C: NO HAY SONIDO EN NINGUNA DE LAS BOCINAS	2:33 p. m.	2:33 p. m.	G2474960	
23	PTS :	2:33 p. m.	2:33 p. m.	G2474960	
24	PTS : Workshop Manual :	2:34 p. m.	2:34 p. m.	G2406681	
25	PTS : PRUEBA PRECISA W: EL DSP (MÓDULO DE PROCESAMIENTO DE SEÑALES DIGITALES DE AUDIO) NO RESPONDE A LA HERRAMIENTA DE DIAGNÓSTICO	2:35 p. m.	2:35 p. m.	G2406681	
26	PTS : Wiring Manual Table of Contents	2:35 p. m.	2:35 p. m.		
27	PTS : 011-1 2025 F-150	2:36 p. m.	2:36 p. m.		
28	PTS : 011-1 2025 F-150	2:36 p. m.	2:36 p. m.		
29	PTS : 011-2 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:36 p. m.	2:36 p. m.		
30	PTS : 011-3 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:36 p. m.	2:36 p. m.		
31	PTS : 011-4 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:36 p. m.	2:36 p. m.		
32	PTS : 011-3 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:36 p. m.	2:36 p. m.		
33	PTS : 011-2 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:36 p. m.	2:36 p. m.		
34	PTS : 011-3 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:36 p. m.	2:36 p. m.		

35	PTS : 011-3 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:36 p. m.	2:36 p. m.		
36	PTS : 011-4 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:37 p. m.	2:37 p. m.		
37	PTS : 011-5 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:37 p. m.	2:37 p. m.		
38	PTS : 011-6 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:37 p. m.	2:37 p. m.		
39	PTS : 011-7 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:37 p. m.	2:37 p. m.		
40	PTS : 011-8 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:37 p. m.	2:37 p. m.		
41	PTS : 011-9 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:37 p. m.	2:37 p. m.		
42	PTS : 011-10 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:37 p. m.	2:37 p. m.		
43	PTS : 011-11 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:37 p. m.	2:37 p. m.		
44	PTS : 011-10 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
45	PTS : 011-10 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
46	PTS : 011-9 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
47	PTS : 011-8 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
48	PTS : 011-8 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
49	PTS : 011-8 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
50	PTS : 011-7 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
51	PTS : 011-7 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
52	PTS : 011-7 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
53	PTS : 011-7 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
54	PTS : 011-8 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
55	PTS : 011-9 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
56	PTS : 011-10 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
57	PTS : 011-10 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
58	PTS : 011-10 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
59	PTS : 011-10 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
60	PTS : 011-10 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
61	PTS : 011-11 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
62	PTS : 011-11 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:38 p. m.	2:38 p. m.		
63	PTS : 011-11 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:39 p. m.	2:39 p. m.		
64	PTS : 011-11 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:39 p. m.	2:39 p. m.		
65	PTS : 011-11 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:39 p. m.	2:39 p. m.		

	PTS : 011-12 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:39 p. m.	2:39 p. m.		
	PTS : 011 -8 INFORMACIÓN DE FUSIBLES Y RELEVADORES	2:39 p. m.	2:39 p. m.		

Signature Not Verified
Digitally signed by CARLOS OSCAR RASPALL GALLI
Date: 2026.09.21 22:33:12 ART